

Dipl.-Ing. Herwarth Reich GmbH




MULTI CROSS RILLO

High flexilble tyre coupling with taper bushings



Your drive is our strength. Your strength is our drive.











Contents

	Page
General technical description	. 3
MULTI CROSS RILLO shaft coupling types	. 4
MULTI CROSS RILLO coupling layout and materials	. 5
Technical Data	. 5
Selection of the proper coupling size	. 6
Assignment to IEC standard motors	. 7
Power Ratings	. 8
Dimensions of MULTI CROSS RILLO shaft couplings	. 9
Dimensions of MULTI CROSS RILLO shaft couplings with spacers	. 10
Ordering information	. 11
Permissible shaft displacement	12
Mounting instructions for MULTI CROSS RILLO shaft couplings	. 12
Instructions for inserting the rubber tyre	. 13
Mounting instructions for MULTI CROSS RILLO shaft couplings with spacer	. 14
Technical note	14
Safety precautions	14

D2C – Designed to Customer

The principle of Designed to Customer describes the recipe for success of REICH-KUPPLUNGEN: Utilizing our product knowledge, our customers are supplied with couplings which are developed and tailor-made to their specific requirements. The designs are mainly based on modular components to provide effective and efficient customer solutions. The unique form of close cooperation with our partners includes consultation, design, calculation, manufacture and integration into existing environments. Adapting our manufacturing to customer-specific production and utilizing global logistics concepts provides better after sales service - worldwide. This customer-oriented concept applies to both standard products and production in small batch sizes.

The company policy of REICH-KUPPLUNGEN embraces, first and foremost, principles such as customer satisfaction, flexibility, quality, prompt delivery and adaptability to the requirements of our customers.

REICH-KUPPLUNGEN supplies not only a coupling, but a solution: Designed to Customer.

Edition February 2013

Proprietary notice pursuant to ISO 16016 to be observed:

The present MULTI MONT RILLO edition renders parts of the previous MULTI MONT RILLO catalogues obsolete. All dimensions in millimeters. We reserve the right to change dimensions and/or design details without prior notice. The reproduction, distribution and utilization of this document as well as the communication of its contents to others without explicit authorization is prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.


General technical description

MULTI CROSS RILLO couplings are highly torsionally flexible tyre couplings with progressive torsional deflection characteristic. The salient feature of the MULTI CROSS RILLO shaft couplings is that the coupling hubs are supplied with commercially available taper bushes for nominal torques of up to 11500 Nm. This allows easy and time saving mounting of the coupling hubs on the shaft. Special tools are not required.

The torque transmission element of the MULTI CROSS RILLO coupling is a rubber tyre reinforced with fabric plies. This tyre transmits the torque without torsional backlash, it is wear-resistant and maintenance-free. The rubber tyre is slit, thus permitting easy radial installation with no need for axial movement of the coupled machines.

MULTI CROSS RILLO shaft couplings reduce torque surges substantially. In applications where torsional vibrations occur the stresses in the drive trains are minimized thanks to their high torsional flexibility.


The use of a rubber tyre as the transmission element compensates to a large extent for axial, radial and angular shaft displacements.



The most important attributes and advantages of the highly flexible MULTI CROSS RILLO couplings

- High torsional flexibility with progressive torsional deflection characteristic
- High compensating capability for axial, radial and angular misalignments
- · Easy and time saving mounting of the coupling hubs thanks to the use of taper bushes
- Radial change of the rubber element without axial movement of the coupled machines
- Backlash-free torque transmission even in case of alternating directions of rotation
- High torsional vibration and shock load damping capability
- Noise level insulation
- Wear-resistant and maintenance-free

MULTI CROSS RILLO shaft coupling types




MULTI CROSS RILLO

Shaft couplingswith taper bushes

Sizes MCR 40 to 60

 $T_{KN} = 24 \text{ to } 125 \text{ Nm}$

Hub type H: taper bush connection from outside Hub type F: taper bush connection from inside




MULTI CROSS RILLO

Shaft couplingswith taper bushes

Größen MCR 70 to 220

 $T_{KN} = 250 \text{ to } 11500 \text{ Nm}$

Hub type H: taper bush connection from outside Hub type F: taper bush connection from inside




MULTI CROSS RILLO

Shaft couplings

Größen MCR 40 to 60

 $T_{KN} = 25 \text{ to } 125 \text{ Nm}$

Hub type B: without taper bush




MULTI CROSS RILLO

Shaft couplings

Größen MCR 70 to 250

 $T_{KN} = 250 \text{ to } 14500 \text{ Nm}$

Hub type B: without taper bush



MULTI CROSS RILLO


Couplings with spacers

Größen MCR 40 to 140

 $T_{KN} = 25 \text{ to } 2350 \text{ Nm}$

The flange hub is also available without taper bush on request..

MULTI CROSS RILLO coupling layout



Item	Specification	Material
1	Coupling hub	GGG 40
2	Rubber tyre	a) Standard version: Natural rubber tyre
	hubber tyre	b) flame-resistant and antistatic: Chloroprene tyre
3	Clamp ring	Steel/GGG 40
4	Taper bush	GG 25
5	Fastening bolt	Grade 8.8

Technical details

Coupling size	Nominal	Nominal Maximum Fati torque torque tor		Dynamic torsional	Relative damping	Maximum speed	Permissibl	e shaftdisp	acement 1)
3126	T _{KN} Nm	T _{Kmax} Nm	T _{KW [10Hz]} Nm	stiffness C _T Nm/rad	Ψ -	n _{max} rpm	axial ∆ K _a mm	radial Δ K _r mm	winklig Δ K _w mm
MCR 40	25	65	11	285	0.9	5500	1.3	1.1	5.7
MCR 50	65	160	26	745	0.9	4500	1.7	1.3	7.0
MCR 60	125	320	53	1500	0.9	4000	2.0	1.6	8.7
MCR 70	250	490	81	2350	0.9	3600	2.3	1.9	10.0
MCR 80	380	760	125	3600	0.9	3100	2.6	2.1	12.0
MCR 90	500	1100	185	5200	0.9	3000	3.0	2.4	13.0
MCR 100	670	1500	250	7200	0.9	2600	3.3	2.6	15.0
MCR 110	880	2150	355	10000	0.9	2300	3.7	2.9	16.0
MCR 120	1350	3550	590	17000	0.9	2050	4.0	3.2	18.0
MCR 140	2350	5650	940	28000	0.9	1800	4.6	3.7	22.0
MCR 160	3800	9350	1560	44500	0.9	1600	5.3	4.2	24.0
MCR 180	6300	16500	2750	78500	0.9	1500	6.0	4.8	28.0
MCR 200	9300	23500	3900	110000	0.9	1300	6.6	5.3	30.0
MCR 220	11500	33000	5550	160000	0.9	1100	7.3	5.8	33.0
MCR 250	14500	42500	7100	200000	0.9	1000	8.2	6.6	37.0

¹⁾ see explanation on page 12

Selection of the proper coupling size

The coupling size should be adequately to ensure that the permissible coupling load is not exceeded in any operating condition encountered. For drives which are not subjected to periodically recurring vibratory torque loads, the coupling design may be selected based on the driving torque with reference to the corresponding service factors.

For specific applications which are subject to periodically recurring high vibratory torques such as combustion engines, piston pumps and compressors, please consult us. Upon request and receipt of your pertinent technical details, we would be pleased to provide a torsional vibration analysis for your specific application.

Calculate the driving torque T_{AN}

Given a driving power P_{AN} and a coupling speed n_{AN} , the driving torque is calculated as follows:

$$T_{AN} [Nm] = 9550 \frac{P_{AN} [kW]}{n_{AN} [rpm]}$$

Select the coupling size

The nominal torque capacity T_{KN} of the coupling shall be at least equal to the max. drive torque T_{AN} while taking the service factors into account

$$T_{KN} \geq T_{AN} \cdot S_A$$

Nominal torque capacity T_{KN} in Nm, T_{AN} in Nm, service factor S_A as per table below

Service factor: S _A	Туре	of operation of the driven	machine							
Prime mover		Load								
	uniform medium shock heavy shock									
Electric motors, turbines, hydraulic motors	1.00	1.75	2.50							
Combustion engines 4 – 6 cylinders	1.25	2.00	2.75							
Combustion engines 1 – 3 cylinders	1.50	2.25	3.00							

Service factor S_A allows for up to 25 starts per hour. For up to 120 starts per hour, the service factor shall be increased by 0.75.

Uniform loads: Agitators (light liquids), centrifugal pumps, blowers and fans ($T \le 100$ Nm), belt conveyors, screw pumps, filling machines, light-weight centrifuges.

Medium shock loads: Agitators (viscous liquids) construction machinery, blowers and fans ($T \le 1000$ Nm), mixers, conveyors, planing machines, plastics industry machinery, textile machines, heavy centrifuges.

Heavy shock loads: Agitators (light liquids), centrifugal pumps, blowers and fans ($T \le 100$ Nm), belt conveyors, screw pumps, filling machines, light-weight centrifuges.

Verify the maximum torque capacity T_{Kmax}

The max. coupling torque capacity T_{Kmax} must be greater than any max. torque T_{max} encountered in operation

$$T_{Kmax} \ge T_{Kmax}$$

Permissible ambient temperature range

For applications at higher ambient temperatures,
please consult us

- 25 °C ≤

Calculation example:

Required: A MULTI CROSS RILLO shaft coupling for driving a planing machine positioned between the electric motor and the gearbox.

Electric motor $P_M = 75$ kW, speed $n_M = 1485$ min⁻¹, power requirement of the planing machine $P_{AN} = 60$ kW, up to 60 starts/hr, ambient temperature 25 °C

Solution: The MULTI CROSS RILLO coupling shall be designed for $P_{AN} = 60$ kW and with a service factor of $S_A = 2.5$ (1,75 as per table plus 0,75 for a starting frequency of more than 25).

Therefore
$$T_{AN} = 9550 \cdot P_{AN} / n_{AN} = 9550 \cdot 60 \text{ kW} / 1485 \text{ min}^{-1} = 385 \text{ Nm} \text{ and}$$

 $T_{KN} \ge T_{AN} \cdot S_A = 385 \text{ Nm} \cdot 2,5 = 965 \text{ Nm}.$

The MULTI CROSS RILLO coupling MCR 120 FF at T $_{\rm KN}$ = 1350 Nm should be selected for the present application.

Assignment to IEC standard motors

MULTI CROSS RILLO shaft couplings for IEC Standard motors acc. to DIN 42637/1

Motor size		power 000 rpm	Coup- ling		power 00 rpm	Couo- ling		power 000 rpm	Coup- ling		power 750 rpm	Coup- ling		extension [mm]
	power P [kW]	torque T [Nm]	MCR	3000 rpm	≤ 1500 rpm									
56	0.09 0.12	0.29 0.38	40 40	0.06 0.09	0.38 0.57	40 40	-						9 >	20
63	0.18	0.57	40	0.12	0.76	40							11	x 23
	0.25	0.80	40	0.18	1.1	40								
71	0.37 0.55	1.2 1.8	40 40	0.25 0.37	1.6 2.4	40 40							14	x 30
	0.75	2.4	40	0.55	3.5	40	0.37	3.5	40					
80	1.1	3.5	40	0.75	4.8	40	0.55	5.3	40				19	x 40
90 S	1.5	4.8	50	1.1	7.0	50	0.75	7.2	50					
90 L	2.2	7.0	50	1.5	9.6	50	1.1	11	50				24	x 50
100 1	3	0.6	F0	2.2	14	50	1 5	1.1	50	0.75	10	50		
100 L	J	9.6	50	3	19	50	1.5	14	50	1.1	14	50	28	x 60
112 M	4	13	50	4	25	50	2.2	21	50	1.5	19	50		
132 S	5.5 7.5	18 24	60 60	5.5	35	60	3	29	60	2.2	28	60		0.0
132 M	-	-	-	7.5	48	60	4 5.5	38 53	60 60	3	38	60	38	x 80
160 M	11	35	70	11	70	70	7.5	72	70	4	51	70		
TOU IVI	15	48	70		70	70	7.5	12	70	5.5	70	70	42 >	110
160 L	18.5	59	70	15	96	70	11	105	70	7.5	96	70		
180 M	22	70	70	18.5	118	70	-	-	-	-	-	-	/10 \	c 110
180 L	-	-	-	22	140	70	15	143	80	11	140	70	40 /	. 110
200L	30	96	80	30	191	80	18.5	177	80	15	191	80	55.	110
2001	37	118	80	00	101		22	210	80	10	101	- 00	007	
225 S	-	-	-	37	236	90	-	-	-	18.5	236	90	55 x 110	60 x 140
225 M	45	143	80	45	287	100	30	287	100	22	280	90		
250 M	55	175	80	55	350	100	37	353	100	30	382	100	60 x 140	65 x 140
280 S				75	478	110	45	430	110	37	471	120	65 x 140	75 x 140
280 M				90	573	120	55	525	120	45	573	120		
315 S				110	700	120	75	716	120	55	700	120		
315 M				132	840	140	90	860	140	75	955	140	65 x 140	80 x 170
315 L				160 200	1019 1273	140 140	110 132	1051 1261	140	90	1146 1401	140 160		
				250		160	160		160			160		
355 L				315	1592 2006	160	200	1528 1910	160	132 160	1681 2037	160	75 x 140	95 x 170
555 L				313	2000	100	250	2388	180	200	2547	180	13 7 140	33 X 170
400L				355	2260	180	315	3008	180	250	3183	180	80 x 170	100 x 200
				400	2547	180						, 50	/ 11.0	


This assignment takes usual loads, service factor $S_A = 1,75$ into account. For other loads, a design according to "Selection of the proper coupling size" on page 6 is required. For plants with predominant periodic excitation, the design shall either comply with DIN 740 part 2, or a torsional vibration analysis shall be conducted. The analysis could be provided by us on request.

Power ratings

Speed	Size	40	50	60	70	80	90	100	110	120	140	160	180	200	220	250
rpm								Powe	er rating	[kW]						
100		0.25	0.69	1.31	2.62	3.98	5.2	7.1	9.2	14.1	24.6	39.8	66	97	120	152
200		0.50	1.38	2.62	5.24	7.96	10.5	14.2	18.4	28.3	49.2	79.6	132	195	241	304
300		0.75	2.07	3.93	7.85	11.94	15.7	21.4	27.6	42.4	73.8	119	198	292	361	455
400		1.01	2.76	5.24	10.47	15.92	20.9	28.5	36.9	56.5	98.4	159	264	390	482	607
500		1.26	3.46	6.54	13.09	19.90	26.2	35.6	46.1	70.7	123	199	330	487	602	759
600		1.51	4.15	7.85	15.71	23.87	31.4	42.7	55.3	84.8	148	239	396	584	723	911
740		1.86	5.11	9.69	19.37	29.4	38.7	52.7	68.2	105	182	294	488	721	891	1124
800		2.01	5.5	10.5	20.9	31.8	41.9	57.0	73.7	113	197	318	528	779	963	1215
960		2.41	6.6	12.6	25.1	38.2	50.3	68.4	88.5	136	236	382	633	935	1156	1458
1200		3.02	8.3	15.7	31.4	47.7	62.8	85.4	111	170	295	477	792	1169		
1480		3.72	10.2	19.4	38.7	58.9	77.5	105	136	209	364	589	976		•	
1600		4.0	11.1	20.9	41.9	63.7	83.8	114	147	226	394	637				
1800		4.5	12.4	23.6	47.1	71.6	94.2	128	166	254	443					
2000		5.0	13.8	26.2	52.4	79.6	105	142	184	283						
2200		5.5	15.2	28.8	57.6	87.5	115	157	203							
2400		6.0	16.6	31.4	62.8	95.5	126	171								
2600		6.5	18.0	34.0	68.1	103	136	185								
2800		7.0	19.4	36.6	73.3	111	147		-							
2960		7.4	20.5	38.7	77.5	118	155									
3100		7.8	21.4	40.6	81.2	123		•								
3600		9.0	24.9	47.1	94.2		·									

The given power ratings apply to theservice factor $S_A = 1,0$, see page 6. For other service conditions and/orother power ratings, the design should be selected according to page 6.


MULTI CROSS RILLO shaft couplings



Coup- ling	Hub type	Taper bush	Bore max.	А	С	D	LH	М	Е	F	G ²)	J ³)	Mass ¹)	Moment of inertia 1)
size			mm	mm	mm	mm	mm	mm	mm	mm	mm	mm	kg	kgm ²
	В	-	32				33		22			-	1.0	0.001
MCR 40	F	1008	32	104	82	-	33	11	22	-	-	29	0.9	0.001
	Н	1008	32				33		22			29	0.9	0.001
	В	-	38				45		32			-	1.9	0.002
MCR 50	F	1210	32	133	100	79	38	13	25	-	-	38	1.4	0.002
	H	1210	32			70	38		25			38	1.4	0.002
1400.00	В	-	45	405	405	70	55	4-7	38			-	3.5	0.005
MCR 60	F H	1610	40 40	165	125	103	42 42	17	25 25	-	-	38 38	2.3 2.3	0.004 0.004
		1610				103						-		
MCR 70	B F	2012	50 50	187	144	80	47 44	12	35 32	100	13	42	3.2 2.6	0.006 0.005
IVICH 70	H	1610	40	107	144	00	42	12	25	100	13	38	2.6	0.005
	B	-	60			98	55		42			-	5.2	0.003
MCR 80	F	2517	60	211	167	97	58	13	45	108	16	48	4.2	0.021
WOTTOO	H	2012	50	211	107	98	45	10	32	100	10	42	4.4	0.012
	В	-	70			112	64		50			-	7.5	0.025
MCR 90	F	2517	60	235	188	108	60	14	45	120	16	48	6.4	0.025
	H	2517	60			108	60		45			48	6.4	0.025
	В	-	80			125	71		57			-	10.9	0.073
MCR 100	F	3020	75	254	216	120	66	14	51	124	16	55	8.6	0.042
	Н	2517	60			113	66		45			48	9.4	0.047
	В	-	90			128	75		62			-	13.5	0.105
MCR 110	F	3020	75	279	233	134	64	13	51	124	16	55	10.9	0.064
	Н	3020	75			134	64		51			55	10.9	0.064
	В	-	100			143	85		70			-	19.2	0.163
MCR 120	F	3525	90	314	264	140	80	15	65	134	16	67	15.2	0.123
	Н	3020	75			140	66		51			55	16.3	0.127
	В	-	130				111		95			-	31.8	0.452
MCR 140	F	3525	90	359	311	178	82	16	65	146	17	67	25.8	0.373
	H	3525	90				82		65			67	25.8	0.373
	В	-	140			187	117		102			-	42.5	0.737
MCR 160	F	4030	100	402	345	197	92	15	77	156	19	80	34.3	0.594
	<u>H</u>	4030	100			197	92		77			80	34.3	0.594
	В	-	150			200	137		114			-	57.6	1.302
MCR 180	F	4535	110	470	398	205	112	23	89	188	19	89	47.2	1.078
	H	4535	110			205	112		89			89	47.2	1.078
MODOO	В	4505	150	F00	400	200	138	0.4	114	000	10	-	71.5	1.847
MCR 200	F	4535	110	508	429	205	113	24	89	206	19	89	61.0	1.592
	<u>H</u>	4535	110			205	113		89			89	61.0	1.592
MCD 000	В	E040	160 125	EGO	171	218	155	00	127	006	20	-	90.0	2.829
MCR 220	F H	5040 5040	125 125	562	474	223 223	130 130	28	102 102	236	20	92 92	77.0 77.0	2.431 2.431
MCR 250	<u>н</u> В	5040	190	628	532	254	162	30	132	250	25	92	112.0	3.645
MON 200	Ь	_	190	020	JJZ	254	102	J 30	132	230	20	_	112.0	3.045

¹⁾ Mass and moment of inertia for complete coupling, including tyre and taper bush 2) G = Space required for removing and changing the rubber tyre 3) J = Space required for fixing and removing the bushes and clamp rings

MULTI CROSS RILLO shaft couplings with spacers



Coupling size		Taper bush			Bohi	rung		Α	С	D	d		E		F	L	K	N	J	Mass ¹⁾	Moment of inertia ¹⁾
	Type F	Туре Н	Type Z	Туре В	Type F	Туре Н	Type Z					Туре В	Type F	Туре Н	Type Z						
				max.	max.	max.	max.									min.	min.	von	bis		
				mm	mm	mm	mm	mm	mm	mm	mm	mm	mm	mm	mm	mm	mm	mm	mm	kg	kgm ²
			1210				32		83	118	25				25	65	6	80		2.6	0.010
MCR 40 Z ²)	1008	1008		32	22	22		104				22	22	22		77	6	100		2.6	0.010
,,			1610				40		80	127	32				25	88	9	100	113	3.2	0.014
			1010				.0									128	9	140	150	3.4	0.015
MCR 50 Z	1210	1210	1610	38	32	32	40	133	80	127	32	32	25	25	25	85	9	100	116	3.2	0.014
WIOTI 30 Z	1210	1210	1010	30	52	02	4	100	00	121	52	52	25	20	25	125	9	140	156	3.4	0.015
MCR 60 Z	1610	1610	1610	45	40	40	40	165	90	127	32	38	25	25	25	78	9	100	124	3.2	0.014
IVICH OU Z	1610	1010	1610	45	40	40	40	100	00	127	32	30	25	25	25	118	9	100	164	3.4	0.015
																80	9	100	114	7.8	0.075
MCR 70 Z ³)	2012	1610	2517	50	50	40	60	187	125	180	48	35	32	25	45	120	9	140	154	8.4	0.080
																160	9	180	194	9.0	0.084
																78	9	100	117	7.8	0.075
MCR 80 Z	2517	2012	2517	60	60	50	60	211	123	178	48	42	45	32	45	116	9	140	158	8.4	0.080
																156	9	180	198	9.0	0.084
																116	9	140	158	8.4	0.080
MCR 90 Z	2517	2517	2517	70	60	60	60	235	123	178	48	50	45	45	45	156	9	180	198	9.0	0.084
																116	9	140	158	14.5	0.202
MCR 100 Z	3020	2517	3020	80	75	60	75	254	146	216	60	57	51	45	51	156	9	180	198	15.4	0.212
																116		140		14.5	0.202
MCR 110 Z	3020	3020	3020	90	75	75	75	279	146	216	60	62	51	51	51	156		180		15.4	0.212
																114	9	140		22.2	0.331
MCR 120 Z	3525	3020	3525	100	90	75	90	314	178	248	80	70	65	51	63	154	_	180		23.8	0.350
																111		140		22.2	0.331
MCR 140 Z	3525	3525	3525	130	90	90	90	359	178	248	80	95	65	65	63						
					- 0		- 0			J						151	9	180	203	23.8	0.350

Dimensions G and H on request. Further dimensions see MCR shaft couplings on page 9

³⁾ MCR 70 F coupling half for spacer shaft required



¹⁾ Mass and moment of inertia for complete coupling, including tyre and taper bush

²⁾ MCR 40 B coupling half for spacer shaft required

Ordering information

The following parts are required for a complete MULTI CROSS RILLO shaft coupling:

- a) 2 coupling halves, each consisting of hub (type F, H or B), clamp ring, fastening bolts
- b) 1 rubber tyre
- c) bFor hub type F or H: taper bush size with indication of the bore dimensions; e.g. bush 3020 with 65 mm bore, corresponding designation: 3020.65, for hub type B only bore diameter requested

Ordering example: 1 MULTI CROSS RILLO shaft coupling size MCR 100 FH

consisting of 1 coupling half MCR 100 F (hub, clamp ring and set of fastening bolts)

1 coupling half MCR 100 H (hub, clamp ring and set of fastening bolts)

1 rubber tyre MCR 100

1 taper bush 3020.65 (keyway acc. to DIN 6885/1) 1 taper bush 2517.48 (keyway acc. to DIN 6885/1)

The following parts are required for a complete MULTI CROSS RILLO shaft coupling with spacer:

- a) 2 coupling halves, each consisting of hub (type F or H), clamp ring, fastening bolts
- b) 1 rubber tyre
- c) For hub type F or H: taper bush size with indication of the bore dimensions; e.g. bush 2517 with 48 mm bore, corresponding designation: 2517.48, for hub type B only bore diameter requested
- d) Flange hub with specification of the taper bush size and the motor shaft diameter, spacer (with indication of the required length L, see page 10) and fastening bolts. The flange hub is also available without a taper bush but with cylindrical bore on request.

Ordering example: 1 MULTI CROSS RILLO coupling with spacer shaft size MCR 90 FF Z

consisting of 2 coupling halves MCR 90 F (hub, clamp ring and set of fastening bolts)

1 rubber tyre MCR 90

1 taper bush 2517.48 (keyway acc. to DIN 6885/1) dimension d, see page 10

1 taper bush 2517.48 (keyway acc. to DIN 6885/1) for pump shaft

1 spacer shaft with L =116 mm

1 flange hub MCR 90 Z

1 taper bush 2517.55 (keyway acc. to DIN 6885/1)


Available taper bushes

Taper bushes mount MULTI CROSS RILLO couplings in a shrink-fit-like manner on the shafts. The taper bushes shown beloware available from stock.

Taper bushes are also available with inch bores.

No.	Metri	c bore	s and	keywa	ys acc	. to DI	N 688	5/1											
1008	9	10	11	12	14	16	18	19	20	22									
1210	11	12	14	16	18	19	20	22	24	25	28	30	32						
1610	14	16	18	19	20	22	24	25	28	30	32	35	38	40	42				
2012	14	16	18	19	20	22	24	25	28	30	32	35	38	40	42	45	48	50	
2517	16	18	19	20	22	24	25	28	30	32	35	38	40	42	45	48	50	55	60
3020	25	28	30	32	35	38	40	42	45	48	50	55	60	65	70	75			
3525	35	38	40	42	45	48	50	55	60	65	70	75	80	85	90				
4030	40	42	45	48	50	55	60	65	70	75	80	85	90	95	100				
4535	55	60	65	70	75	80	85	90	95	100	105	110							
5040	70	75	80	85	90	95	100	105	110	115	120	125							


Permissible shaft displacements of MULTI CROSS RILLO couplings



The indicated values for ΔK_w [mm] = S_{max} – S_{min} (page 5) correspond to an angular displacement of ΔK_w = 4°. This permissible angular shaft displacement is the max. angular misalignment of the coupling halves which may only be fully utilized when no axial and radial misalignments exists. An angular displacement of ΔK_w = 2° is permissible when axial and radial misalignments of ½ ΔK_a and ½ ΔK_r are present.

Mounting instructions for MULTI CROSS RILLO shaft couplings

- The outer taper of the bush and the hub bore with inner taper shall be bright and free from grease prior to assembly. Any preservatives shall be removed completely.
- 2. Insert the bush into the coupling hub making sure that all connecting bores are lined up. This means that the threaded half holes shall be opposite the plain half holes (Fig. 1).
- 3. Lightly oil or grease the mounting screws and screw them in loosely. Do not tighten the screw yet (Fig. 2).
- 4. Push the coupling hub with inserted taper bush onto the cleaned shaft with key and position it properly so that the clearance M (see Table 1 and Fig. 3) is maintained. Attach the (outer or inner) clamp ring loosely prior to assembly of the hub.
- 5. Tighten the screws uniformly with a torque wrench to half of the specified tightening torque M_{A2} (Table 2).
- 6. Hold a piece of wood or brass against the bush and hit it lightly with a hammer and tighten the screws to the specified tightening torque M_{A2} (Table 2). Repeat, if necessary.






Table 1: Clearance M and tightening torques for mounting the clamp ring

Coupling size MCR	40	50	60	70	80	90	100	110	120	140	160	180	200	220	250
Clearance M [mm]	22	25	33	23	25	27	27	25	29	32	30	46	48	55	59
Screw size	M5	M6	M6	M8	M8	M10	M10	M10	M12	M12	M16	M16	M16	M20	M20
Number of screws	4	4	10	10	12	12	12	12	12	16	16	20	24	24	28

Tightening torque MA₁ on request.


Table 2: Tightening torques for mounting the taper bushes

Coupling size MCR	40	50	60	70	80	100	120	160	180	200
			70	80	90	110	140		200	
					100	120				
Taper bush Nr.	1008	1210	1610	2012	2517	3020	3525	4030	4535	5040
Screw size B.S.W. *)	¹/₄ x 13	³/ ₈ x 16	³/ ₈ x 16	⁷ / ₁₆ x 22	½ x 25	5/8 x 32	½ x 38	⁵/ ₈ x 45	³/ ₄ x 51	⁷ / ₈ x 57
Tightening torque M _{A2} [Nm]	5.7	20	20	31	49	92	115	172	195	275
Screw size SW [mm]	3	5	5	6	6	8	10	12	14	14

^{*)} No. 1008/1210/1610/2012/2517/ 3020 set screw; *) Nr. 3525/4030/4535/5040 socket head cap screws

Removing the coupling hubs with taper bushes

- Loosen and remove all screws. Depending on the taper bush size, screw 1 or 2 greased screws into the half threaded push-off holes of the taper bush (Fig. 5).
- 2. Tighten the screws uniformly until the bush detaches from the hub...
- 3. BThe hub can be pulled off the shaft together with the taper bush as soon as the taper bush is detached.



Instructions for inserting the rubber tyre

- Make sure that the coupling hubs are positioned at right angles on the shaft ends. Align the coupling hubs to each other in the axial, radial and angular directions. See also permissible shaft displacements on pages 5 and 12. The radial and angular displacements should be kept as small as possible, particularly in high speed applications.
- 2. Pull the rubber tyre that is slit for assembly apart and place it over the coupling hub. Make sure that the tyre lies completely against the hub. If not, apply light hammer blows onto the outer contours of the tyre. After completion of the assembly, a gap as specified in Table 3 shall exist between the ends of the rubber tyre.
- 3. Fit the remaining clamp rings, if any, and tighten the screws hand-tight. Thereafter, tighten them uniformly in an alternating sequence (half a turn each) until the specified tightening torque M_{A1} (Table 1 on page 13 and Fig. 4 on page 12) is reached.

Gap

Table 3


Coupling size MCR	40 to 60	70 to 120	140 to 160	180 to 250
Rubber tyre gap [mm]	2	3	5	6

Mounting instructions for MULTI CROSS RILLO shaft couplings with spacer

- 1. According to the mounting instructions for MULTI CROSS RILLO shaft coupling hubs with taper bushes shall be mounted completely on the shaft ends. It is important to make sure that the coupling hubs are flush with the shaft ends to enable subsequent assembly or disassembly of the spacer.
- 2. Mount the flange hub properly on the shaft. It is important to ensure that the flange hub does not protrude from the shaft end.
- 3. Mount the spacer (with the coupling hub placed on the top) to the flange hub using the proper tightening torque M_{A3} (Table 4).
- 4. Align the MULTI CROSS RILLO coupling and insert the tyre according to the above instructions.

Table 4: Tightening torques for mounting the spacers

Coupling size MCR	40		50	60	70	80	90	100	110	120	140
Screw size	M6	M8	M8	M8	M10	M10	M10	M16	M16	M16	M16
Number of screws	6	6	6	6	6	6	6	8	8	8	8
Tightening torque M _{A3} [Nm]	10	25	25	25	50	50	50	210	210	210	210



For dimensions L, N, K and A see page 10

Technical note:


The technical data applies only to the complete coupling or the corresponding coupling elements. It is the customer's/ user's responsibility to ensure there are no inadmissible loads acting on all the components. Especially existing connections, like bolt connections, have to be checked regarding the transmittable torque, if necessary other measures, e.g. additional reinforcement by pins, may be required. It is the customer's/user's responsibility to make sure the dimensioning of the shaft and keyed or other connection, e.g. shrinking or clamping connection, is correct.

REICH-KUPPLUNGEN have an extensive programme of couplings and coupling systems to cover nearly every drive configuration. Furthermore customized solutions can be developed and be manufactured also in small series or as prototypes. Calculation programmes are available for coupling selection and sizing. - Please challenge us!

Safety precautions

It is the customer's and user's responsibility to observe the national and international safety rules and laws. Proper safety devices must be provided for the coupling to prevent accidental contact.

Check all bolted connections for the correct tightening torque and fit after a short running period preferably after a test run.



Contact person: Department: Tel.:Fax:							
<u></u>							
Input side:							
Maschinenfabrik Prime mover: Diesel engine / hyd	Prime mover: Diesel engine / hydraulic / electric moto						
DiplIng. Herwarth Reich GmbH Post box 10 20 66 Others:	Others:						
Nominal power: kW at							
D - 44720 Bochum Speed range: from							
Max. starting/shock torque:							
nquiry: Order: Output side:							
Driven machine:	Driven machine:						
Nominal power:							
General system details: Max. load torque:							
nvironmental conditions/place of installation: In case of uneven torque load:							
from to	Nn						
oad: uniform medium shock heavy shock medium shock shock medium shock shock shock medium shock sho							
mbient temperature at the coupling:°C Balancing: yes	по П						
paily period of operation: hours/day Balancing speed: rpm /							
tarting frequency: per hours Balancing with keyway: yes	_						
Displacement: Annotations:							
K _a : mm / ΔK _r : mm / ΔK _w : °							
							
haft dimensions:							
	T						
urther coupling design specifications (e.g. with brake drum/brake disc/material):							
urther details of the complete system / principle sketch of installation situation:							
urther details of the complete system / principle sketch of installation situation:							

